LA-UR-08-0997

Approved for public release; distribution is unlimited.

Title:	ANALYTIC VERIFICATION OF NON-BOLTZMANN PROBLEMS
Author(s):	AVNEET SOOD LANL, X-3
Intended for:	NORTH CAROLINA STATE UNIVERSITY NUCLEAR ENGINEERING DEPT FEBRUARY 2008



Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

Analytic Verification of Non-Boltzmann Problems

Avneet Sood

Los Alamos National Laboratory Applied Physics (X) Division X-3 Computational Analysis and Simulations Group, Monte Carlo Team A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Motivation for this work

- Upcoming release of MCNP 5.1.50
 - Major feature: allows pulse-height tallies with all of MCNP's variance reduction
 - Pulse-height tallies are non-Boltzmann
 - · Traditional methods of verification do not apply
 - Very easy to make a mistake when developing variance reduction theory for pulse-height tallies
 - How do you know that you did not make a mistake?

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons





Motivation

Introduction

- Analytic Verification The Probablistic Approach
- 3 Pulse-Height Spectra
- 4 Verification Test Problem
- 5 Verification Problem Solution
- Pulse Height Results: Analytic and Calculated Photons Photons and Electrons

7 Conclusions

A. Sood

Motivation

Introduction Anaytic Wrification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons





A Personal View of Computer Simulation of Radiation Transport



A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons

- Types of analytic code verification
 - Line-by-line examination of algorithm, Comparison to other codes, Regression test suite, Alternate problem representation
 - High precision analytic results





Generating high-precision analytic results

- Radiation transport codes begin with Boltzmann transport equation (BTE)
 - Transport is a function of 3-D space, energy, time, ...
- Deterministic techniques (eg. S_n)
 - discretize each variable, and 'moves' particles from one differential phase space to the next, estimates average behaviour, provides precise answers everywhere
- Monte Carlo:
 - 'moves' particles from event to event, no approximations in space, energy, time; provides exact physics, and calculates average answers locally
- Common approach for analytic verification for both methods simplify/eliminate terms in BTE
 - 1-D, single energy, isotropic scattering, steady-state
- Generate high-precision answers and compare calculations



Motivation

Introduction

Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Probablistic approach to analytic verification:

- New approach:
 - The main difficulty in verification of transport codes is in the complexity of nuclear data.
 - Solution: Simplify physical data (nuclear cross sections), leaving mathematical equations and code unaltered such that:
 - A limited set of occurrences exists (few?)
 - Probability of each occurrence can be calculated (easily?)
 - Control the code by controlling the nuclear data!
- Approach allows analytic verification of codes that is independent of solution technique and theoretical description:
 - deterministic vs. Monte Carlo, Boltzmann vs non-Boltzmann
- This approach is not widely used (or known?)



A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons



Pulse-Height Tallies



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results

Photons Photons and Electrons





What are Pulse-Height tallies?

- Pulse-height tallies record energy deposited by source particle and all progeny
- Simulates 'perfect' radiation detector
 EXAMPLE HISTORY







Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons

Photons and Electrons



Calculation of Pulse-Heights

- Monte Carlo is the only way to calculate this from first principles
 - · Cannot be described by Boltzmann transport equation
 - Unlike other quantities (flux, current) which are calculated as particle exits or collides in a cell (Boltzmann-like)
 - Requires completion of all tracks for a history before the tally is made (joint PDFs)
 - Tally is done on a collection of particles
 - Boltzmann quantities (eg flux, current, etc) ignore any correlation between particles
- Requires microscopically correct data energy must be conserved.



Motivation

Introduction

Analytic Verification Probablistic approach

Pulse-height Spectra

/erification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Verification Test Objectives

- Why are we interested in pulse-height tallies?
 - Pulse-height tallies have been available in MCNP since mid-80's
 - No analytic verification has been done
- Traditional analytic verification methods rely on BTE simplifications
 - Traditional methods cannot help
 - Probablistic approach can help
- Analytic verification problem must be:
 - Analytic verification problem is as physically realistic as possible (i.e non-trivial)
 - Analytically verify PHT (standard MCNP)
 - Analytically verify PHT with Variance Reduction a major feature of next release!!
 - Ideally: also verify Boltzmann-type tallies in MCNP

A. Sood

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

/erification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





The analytic test problem...



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Definition of Test Problem

- Very clever isotopes defined by Ted Shuttleworth!!!¹
- Only gives examples of test cases. Scratched the surface of the complete solution.²
- Defined fictitious isotopes defining physics of "Middle Earth"³
 - If you can control the data, you can control the code...
 - Two cylinders: length of ln(2), radius ln(2)
 - Monodirectional point source along cylindrical axis: 3.2 MeV
 - · Homogenous materials comprised of fictitious isotopes

¹Shuttleworth, T., "The Verification of Monte Carlo Codes in Middle Earth," Proc. of 8th Int. Conf. Rad. Shield., Arlington, Tx (1994).

² Personal communication, (2002).

³ J.R.R. Tolkien, The Lord of the Rings, Unwin Books London (1974).

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Trati Problem Verification Problem Solution Pulse Height Results Photons Photons and Electrons

A. Sood







Collision Physics



Notivation Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons and Electrons

A. Sood





Shuttleworth's Fictitious Isotopes

- Moron (chemical symbol: Mo)
 - Pure absorber
 - Analogous to photoelectric effect
 - 0.2 atom fraction
- Odium (chemical symbol: O)
 - Undeflected secondary particle with 1/2 initial energy
 - Analogous to Compton scattering
 - 0.3 atom fraction
- Kneeon (chemical symbol: Kn)
 - Produces 2 secondary particles with 1/4 initial energy
 - < 1 MeV: both particles undeflected
 - > 1 MeV: one particle undeflected, one particle 90° scatter
 - Analogous to pair production
 - 0.5 atom fraction



Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

/erification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Comments on problem details

- $\Sigma_t = 1.0 \text{ cm}^{-1}$, Energy cutoff of 0.15 MeV (absorption)
- Sampling of Kneeon data must be correlated
- Collisions continuous in space
- Particles can multiply and produce progeny
- Forward and radial scattering; no backwards scattering
- Discrete energy deposition
- Each possible collision can be analytically calculated using sophomore level nuclear engineering/physics*

* B.J. Adams, Reed College Phys. Dept., summer 2002

* M.S. Reed, TAMU Nucl. Eng. Dept, summer 2003,2004

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutior Pulse Height Results Photons Photons and Electrons Conclusions





Scenario Tree

Interaction Key Moren Collision Odium Collision Kneeco Collision Abitrary Collision Exit	Momenclature G#: Subsection of history tree corresponding to group # (R1): Subsection of history tree representing second radial scatter track (R2): Subsection of history tree representing second radial scatter track (Fwd.): Location of a dual forward scatter in history tree		
(R1) (Fwd) (Fwd)	GI (R2) (R2) (Freed) (Freed) (Freed) (G4) (G4) (G4) (G5)		

- 161 possible histories; 0 to 7 collisions possible
- 5 discrete energies





Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

/erification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





Calculating the Analytic Solution

- All probabilites are calculated using sophomore level physics:
 - e^{-Σx} is the probability of travelling a distance x without a collision, and Σdx is the probability of having a collision in dx
 - The probability of at least one collision between points *a* and *b* is:

$$\int_{b}^{a} e^{-\Sigma x} \Sigma dx = e^{-\Sigma(b-a)}$$

· Don't let this fool you...the devil is in the details

A. Sood

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

/erification Problem Solution

Pulse Height Results Photons Photons and Electrons





N Collisions followed by an escape:



- Pulse-heights:
 - calculate probability of event occurring and energy deposited:
 - (reaching *a* without collision) x (collision at *da*) x (reaching *L* without collision) $\int_{0}^{L} (e^{-\Sigma a})(\Sigma da)(e^{-\Sigma(L-a)}) = \Sigma(L)e^{-\Sigma(L)}$
- For *n* collisions followed by an escape, this can be generalized (for Σ = 1, Detector length = L) to:

$$p_{\rm esc}(n) = \frac{(L)^n e^{-L}}{n!}$$



Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

/erification Problem Solution

Pulse Height Results

Photons Photons and Electrons





N Collisions followed by an escape:



• Volume Flux : calculate (Track length / volume)

$$< T_I >= rac{\int_0^L a(e^{-\Sigma a})(\Sigma da)(e^{-\Sigma(L-a)})}{\int_0^L (e^{-\Sigma a})(\Sigma da)(e^{-\Sigma(L-a)})}$$

 For *n* collisions followed by an escape, this can be generalized (for Σ = 1, Detector length = L) to:

$$< T_{l-esc} >= \frac{L}{n+1}$$



Motivation

Introduction

Analytic Verification Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





N-1 Collisions followed by an absorption:



- Pulse-heights:
 - calculate probability of event occurring and energy deposited:
 - (reaching a without collision) x (collision at da)

$$\int_0^L (e^{-\Sigma a})(\Sigma da) = 1 - \Sigma e^{-\Sigma(L)}$$

 For n – 1 collisions followed absorption, this can be generalized (for Σ = 1, Detector length = L) to:

$$p_{abs}(n) = \frac{e^{(-L)}[(n-1)!e^{L} - (L)^{n-1} - (n-1)(L)^{n-2} - (n-1)(n-2)(L)^{n-3} \dots]}{(n-1)!}$$



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results

Photons

Photons and Electrons





N-1 Collisions followed by an absorption:



<u>Volume Flux</u>: calculate (Track length / volume)

$$< T_I >= rac{\int_0^L a(e^{-\Sigma a})(\Sigma da)}{\int_0^L (e^{-\Sigma a})(\Sigma da)} = rac{\Sigma e^{-\Sigma(L)} - L - 1}{\Sigma e^{-\Sigma(L)} - 1}$$

 For n – 1 collisions followed absorption, this can be generalized (for Σ = 1, Detector length = L) to:

$$T_{I-abs}(n) = \frac{n!e^{(-L)} - L - nL^{n-1} - (n-1)(n)L^{n-2}}{n!e^{(-L)} - nL^{n-1} - (n-1)(n)L^{n-2}}$$

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons

Photons and Electrons





Comments on Analytic Solution

- Equations for $p_{esc}(n)$, and $p_{abs}(n)$ account for most interactions.
- "Pair production" collisions below 1 MeV produce two identical particles which require special handling and additional (non-trivial) equations





A. Sood

Motivation

Introduction

Analytic Verification Probablistic approach

r aloo noigin opoolia

Verification Test Problem

erification Problem Solution

Pulse Height Results Photons Photons and Electrons



Example Track_{Example History for Region 1}



P = (2 axial collisions) x (1 radial collision)

• =
$$(0.5)(0.3)\frac{(ln2)^2e^{-ln2}}{2}(0.2)(1-e^{-ln2})$$

 $\bullet = 0.0018017$

2.8 MeV deposited with probability = 0.0018017









Generating high precision analytic results

- Analytic computer code developed¹
 - · Indexing over unique history labeling scheme
 - · First region axial leakage source for second region
- For all possible histories
 - Pulse height values calculated
 - Particle currents, leakage and volume fluxes calculated²
- · Verification of analytic computer code results
 - Selective hand calculation
 - Sum of history probabilities at different tree locations and over all energies and histories

¹A. Sood (LANL), M.S. Reed (TAMU), R.A. Forster (LANL),"New Results for Pulse-Height Tally Verification" Trans. Amer. Nucl. Soc., 89, 456 (November 2003).

² Unpublished

A. Sood

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results Photons

Photons and Electrons





Applying the analytic test problem...



Motivation

Introduction Analytic Verification Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solutio

Pulse Height Results

Photons

Photons and Electrons





Implementing Analytic Problem:

- Practical problems with probabilistic approach and MCNP
 - Pulse-height tallies are usually for photon/electron problems
 - Physical interactions for photons is hard-coded. Controlling the physics through the data will not work.
 - Very simple code modifications will be required.
- MCNP 5.1.50 calculated results generated for:
 - F1: photon current across interface, last axial surface along diameter for both cylinders
 - F2: photon surface flux across interface, last axial surface along diameter in each cylinder
 - F4: photon volume flux in each cylinder
 - · F8: pulse-heights in each cylindrical volumes
 - *F8: total energy deposited in each cylindrical volume



Motivation

ntroduction Analytic Verification Probabilistic approach Pulse-height Spectra Jerrification Test Problem /errification Problem Solution Pulse Height Results

Photons Photons and Electrons





MCNP5.1.50 PHT-VR Verification: Photon Results - analog

Table: Photon Current, Flux Results

		Energy	Analytic	MCNP 5	Number of
		(MeV)		(R.E.)	S.D away
photon	Axial interface		0.8899430000	0.889896 +/- 0	0
current	Last axial surface		0.7643510000	0.764251 +/- 0.0001	-1.31
	Diameter				
	Region 1		0.2542390000	0.254223 +/- 0.0002	-0.31
	Region 2		0.1428180000	0.142860 +/- 0.0003	0.98
photon	Axial interface	0.20	0.0431240772	0.043106 +/- 0.0005	-0.84
surface		0.40	0.0243696716	0.024377 +/- 0.0005	0.60
flux		0.80	0.1219679960	0.121936 +/- 0.0002	-1.31
		1.60	0.0688836141	0.068877 +/- 0.0003	-0.30
		3.30	0.3312601617	0.331278 +/- 0.0001	0.54
		total		0.589574 +/- 0	
	Last axial surface				
		0.20	0.0930220670	0.092980 +/- 0.0003	-1.52
		0.40	0.0497322033	0.049750 +/- 0.0004	0.88
		0.80	0.1291299684	0.129123 +/- 0.0002	-0.27
		1.60	0.0688836141	0.068885 +/- 0.0003	0.05
		3.30	0.1656300809	0.165595 +/- 0.0002	-1.06
		total		0.506332 +/- 0.0001	
	Diameter				
	Region 1	0.20	0.0303893949	0.030402 +/- 0.0004	1.07
		0.40	0.0124222561	0.012420 +/- 0.0005	-0.40
		0.80	0.0414075202	0.041392 +/- 0.0003	-1.25
	Region 2	0.20	0.0160899440	0.016097 +/- 0.0006	0.73
		0.40	0.0105163539	0.010522 +/- 0.0006	0.95
		0.80	0.0207037601	0.020705 +/- 0.0004	0.10

A. Sood

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





MCNP5.1.50 PHT-VR Verification: Photon Results - analog

Table: Photon Volume Flux Results

		Energy	Analytic	MCNP 5	Number of
		(MeV)		(R.E.)	S.D away
photon	Region 1	0.20	0.0552739100	0.055267 +/- 0.0004	-0.31
Volume	-	0.40	0.0316929622	0.031707 +/- 0.0004	1.08
flux		0.80	0.1956661722	0.195609 +/- 0.0002	-1.46
		1.60	0.0439941693	0.043989 +/- 0.0003	-0.43
		3.20	0.4779073926	0.477914 +/- 0.0000	0
		total		+/-	
	Region 2				
	-	0.20	0.0905357642	0.090521 +/- 0.0003	-0.54
		0.40	0.0618684956	0.061891 +/- 0.0003	1.23
		0.80	0.1903885628	0.190389 +/- 0.0002	0.01
		1.60	0.0716861089	0.071685 +/- 0.0003	-0.05
		3.20	0.2389536963	0.238945 +/- 0.0001	-0.36
		total			

A. Sood

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons





MCNP5.1.50 PHT-VR Verification: Photon Results - analog Table: Photon Pulse-Height Results

		Energy	Analytic	MCNP 5	Number of
		(MeV)		(R.E.)	S.D away
	Region 1		1.1252880000	1.125290 +/- 0.0001	0.02
	Region 2		0.6885630000	0.688757 +/- 0.0001	2.82
photon					
pulse	Region 1	0.10	0.5000000000	0.500026 +/- 0.0001	0.52
height		1.60	0.1906154747	0.190560 +/- 0.0002	-1.46
		2.00	0.0607580302	0.060770 +/- 0.0004	0.49
		2.20	0.0251175286	0.025103 +/- 0.0006	-0.97
		2.40	0.0685966790	0.068608 +/- 0.0004	0.40
		2.60	0.0100059394	0.009994 +/- 0.0010	-1.19
		2.80	0.0241757434	0.024175 +/- 0.0006	-0.05
		3.00	0.0057451938	0.005749 +/- 0.0013	0.57
		3.20	0.1149854109	0.115015 +/- 0.0003	0.86
		total		1.000000 +/- 0.0000	
	Region 2	0.10	0.4260696364	0.425953 +/- 0.0001	-2.74
		0.20	0.0237685679	0.023765 +/- 0.0006	-0.25
		0.40	0.0630209469	0.063003 +/- 0.0004	-0.71
		0.60	0.0197690310	0.019774 +/- 0.0007	0.34
		0.80	0.0499450801	0.049939 +/- 0.0004	-0.32
		1.00	0.0028098955	0.002813 +/- 0.0019	0.65
		1.20	0.0130114830	0.013023 +/- 0.0009	0.94
		1.40	0.0021885293	0.002190 +/- 0.0021	0.36
		1.60	0.1094651813	0.109498 +/- 0.0003	1.00
		2.00	0.0303790151	0.030382 +/- 0.0006	0.15
		2.20	0.0125587643	0.012574 +/- 0.0009	1.37
		2.40	0.0342983395	0.034307 +/- 0.0005	0.48
		2.60	0.0050029697	0.005002 +/- 0.0014	-0.20
		2.80	0.0120878717	0.012117 +/- 0.0009	2.70
		3.00	0.0028725969	0.002874 +/- 0.0019	0.20
		3.20	0.0574927055	0.057490 +/- 0.0004	-0.12
		total		0.864703 +/- 0.0000	



A. Sood

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solut Pulse Height Results Photons Photons and Electrons Conclusions



MCNP5.1.50: Pulse-Height Tallies with Variance Reduction

- Pulse height (F8) tallies depend on collections of particles (the entire particle history) and are correlated.
 - Two 1 MeV photons originating from the same event and absorbed in one cell registered as single event at 2 MeV; not two events at 1 MeV counts
 - Assumes both photons have weight one.
 - Not the case when using variance reduction
- Create "trees" to keep track of relationship between individual particles
 - Weight assigned to branches of the tree
 - · Energy deposited and weight stored for each branch

A. Sood

Motivation

Introduction Analytic Verification Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons Photons and Electrons





Example: PHT with Variance Reduction



Pulse height tallies require knowledge of the entire particle history A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons and Electrons

Conclusions

E_{ij} is the energy deposited on branch_{ij}.

 w_{ij} is the weight multiplier for branch_{ij}.





Example: PHT with Variance Reduction



Choice 3 Energy deposited: $E_{01} + E_{11} + E_{53}$ Tree weight: $w_{01}w_{11}w_{53}$

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons and Electrons Conclusions





Example: PHT with Variance Reduction

- · Variance Reduction with Pulse-Height Tallies works for:
 - Geometry / Energy / Time splitting and Roulette
 - Weight Window
 - Exponential Transform
 - Forced Collision
 - DXTRAN
 - Implicit Capture / Weight Cutoff
- Current limitations:
 - Coupled Neutron transport (eg. (n,γ))
 - Electron specific variance reduction
 - Controls types and how many specific types of electrons are produced
 - eg. bremsstrahlung, photon-induced secondary electrons, electron-induced x-rays, knock-on electrons



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons

Photons and Electrons





Verification MCNP5 PHT with Variance Reduction

Each MCNP VR technique tested; and most combinations

Table: Photon PHT-VR Results Summary

non-integer geom. split / Russ.Roul	WW (generation)
non-integer geom. split / Russ.Roul off	WW usage
Impl Cap. / Wgt Cutoff	WW + Forc. Col.
DXTRAN	WW + Exp. Trans.

- Sequential, MPI/OMP (16 processors, 2 threads each)
- · Results are very similar to analog case
 - All results < 2.5 SD away from analytic normally distributed
 - All results match analytic to 5-6 decimal places





Votivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons Al Electrons

Analytic Problem with ELECTRONS...

- Is it possible to extend this for electron problems?
 - · Pulse-height tallies are usually for photon/electron problems
 - Electrons are NOT included in analytic test problem
 - Solution: allow ALL secondary progeny (electrons, brem, xrays, etc)
 - ...but do NOT allow them to escape
 - reflective boundaries for jgp > 1
 - More code modifications required...

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons and Electrons





MCNP5.1.50 PHT-VR Verification: Photon/Electron Results - analog

Table: Photon/Electron Surface Current, Flux Results

		Energy	Analytic	MCNP 5	Number of
		(MeV)		(R.E.)	S.D away
photon	Axial interface		0.8899430000	0.89000800 +/- 0.0001	0.732
current	Last axial surface		0.7643510000	0.76441600 +/- 0.0001	0.852
	Diameter				
	Region 1		0.2542390000	0.25422100 +/- 0.0002	-0.36
	Region 2		0.1428180000	0.14286100 +/- 0.0002	1.502
photon	Axial interface	0.21	0.0431240772	0.04316740 +/- 0.0005	2.013
surface		0.41	0.0243696716	0.02435120 +/- 0.0005	-1.53
flux		0.81	0.1219679960	0.12196600 +/- 0.0002	-0.04
		1.61	0.0688836141	0.06886820 +/- 0.0003	-0.71
		3.30	0.3312601617	0.33129500 +/- 0.0001	1.051
		total		0.58964800 +/- 0.0001	
	Last axial surface				
		0.21	0.0930220670	0.09303850 +/- 0.0002	0.886
		0.41	0.0497322033	0.04973090 +/- 0.0002	-0.11
		0.81	0.1291299684	0.12915800 +/- 0.0002	1.094
		1.61	0.0688836141	0.06886780 +/- 0.0002	-1.13
		3.30	0.1656300809	0.16564500 +/- 0.0002	0.451
		total		0.50644100 +/- 0.0001	
	Diameter				
	Region 1	0.21	0.0303893949	0.03038914 +/- 0.0003	-0.0
	-	0.41	0.0124222561	0.01242094 +/- 0.0004	-0.2
		0.81	0.0414075202	0.04140325 +/- 0.0002	-0.53
	Region 2	0.21	0.0160899440	0.01609724 +/- 0.0003	1.51
		0.41	0.0105163539	0.01051566 +/- 0.0003	-0.2
		0.81	0.0207037601	0.02071140 +/- 0.0002	1.84

A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons And Electrons





MCNP5.1.50 PHT-VR Verification: Photon/Electron Results - analog

Motivation

Introduction

Analytic Verification

Probablistic approach

Pulse-height Spectra

Verification Test Problem

Verification Problem Solution

Pulse Height Results

Photons

Photons and Electrons

Conclusions

Table: Photon/Electron Volume Flux Results

		Energy (MeV)	Analytic	MCNP 5 (R.E.)	Number of S.D away
photon	Region 1	0.20	0.0552739100	0.0552899 +/- 0.0003	0.96
Volume	, s	0.40	0.0316929622	0.0316829 +/- 0.0003	-1.06
flux		0.80	0.1956661722	0.1956360 +/- 0.0001	-1.54
		1.60	0.0439941693	0.0439897 +/- 0.0003	-0.34
		3.20	0.4779073926	0.4779150 +/- 0.0001	0.16
		total		0.8045130 +/- 0.0001	
	Region 2				
		0.20	0.0905357642	0.0905709 +/- 0.0002	1.94
		0.40	0.0618684956	0.0618616 +/- 0.0002	-0.56
		0.80	0.1903885628	0.1904200 +/- 0.0001	1.65
		1.60	0.0716861089	0.0716742 +/- 0.0002	-0.83
		3.20	0.2389536963	0.2389720 +/- 0.0002	0.38
		total		0.6534990 +/- 0.0001	





MCNP5.1.50 PHT-VR Verification: Photon/Electron Results - analog Table: Photon/Electron Pulse-Height Results

		Energy	Analytic	MCNP 5	Number of
		(MeV)		(R.E.)	S.D away
	Region 1		1.1252880000	1.124570 +/- 0.0003	-2.13
	Region 2		0.6885630000	0.688837 +/- 0.0005	0.80
photon					
electron	Region 1	0.10	0.5000000000	0.5001420 +/- 0.0003	0.95
pulse	-	1.60	0.1906154747	0.1908020 +/- 0.0007	1.40
height		2.00	0.0607580302	0.0608153 +/- 0.0012	0.78
-		2.20	0.0251175286	0.0251221 +/- 0.002	0.09
		2.40	0.0685966790	0.0685187 +/- 0.0012	-0.95
		2.60	0.0100059394	0.0099869 +/- 0.0031	-0.61
		2.80	0.0241757434	0.0241125 +/- 0.002	-1.31
		3.00	0.0057451938	0.0057073 +/- 0.0042	-1.58
		3.20	0.1149854109	0.1147930 +/- 0.0009	-1.86
		total		1.0000000 +/- 0	
	Region 2	0.10	0.4260696364	0.4260740 +/- 0.0004	0.03
		0.20	0.0237685679	0.0237754 +/- 0.002	0.14
		0.40	0.0630209469	0.0630173 +/- 0.0012	-0.05
		0.60	0.0197690310	0.0196798 +/- 0.0022	-2.06
		0.80	0.0499450801	0.0500267 +/- 0.0014	1.17
		1.00	0.0028098955	0.0028265 +/- 0.0059	1.00
		1.20	0.0130114830	0.0130714 +/- 0.0027	1.70
		1.40	0.0021885293	0.0022040 +/- 0.0067	1.05
		1.60	0.1094651813	0.1096690 +/- 0.0009	2.06
		2.00	0.0303790151	0.0303492 +/- 0.0018	-0.55
		2.20	0.0125587643	0.0125636 +/- 0.0028	0.14
		2.40	0.0342983395	0.0343137 +/- 0.0017	0.26
		2.60	0.0050029697	0.0050024 +/- 0.0045	-0.03
		2.80	0.0120878717	0.0120436 +/- 0.0029	-1.27
		3.00	0.0028725969	0.0028625 +/- 0.0059	-0.60
		3.20	0.0574927055	0.0574907 +/- 0.0013	-0.03
		total		0.8649690 +/- 0.0001	

A. Sood

Motivation Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solution Pulse Height Results Photons Photons Ad Electrons Conclusions





Verification MCNP5 PHT with Variance Reduction

- Photons physics: Brem, annihilation
- Electrons physics: Compton, PE, Auger, Knock-on
- Each MCNP VR technique tested; and most combinations

Table: Photon PHT-VR Results Summary

non-integer geom. split / Russ.Roul	WW (generation)
non-integer geom. split / Russ.Roul off	WW usage
Impl Cap. / Wgt Cutoff	WW + Forc. Col.
DXTRAN	WW + Exp. Trans.

- Sequential, MPI/OMP (16 processors, 2 threads each)
- · Results are very similar to analog case
 - All results < 2.5 SD away from analytic normally distributed
 - All results match analytic to 5-6 decimal places



A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons





Summary: Analytic Verification of PHT-VR in MCNP5.1.50

MCNP5.1.50 pulse-height tallies with VR has been analytically verified

- Calculated analog results for F1, F2, F4, F8, and *F8 tallies compared very well with analytic solution
- Sequential, MPI/OMP 16 processors with 2 threads each
- Virtually all MCNP5.1.50 variance reduction techniques tested...
 - Most combinations of VR tested
 - Energy splitting, time split techniques not tested...
- Results are < 2.5 SD from analytic normally distributed
- Not all physical events tested...
 - no double fluorescence...
- Can be extended to coincidence/anti-coincidence counting
- Extend problem physics to include backwards scattering



A. Sood

Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons and Electrons



Summary: Probabilistic Approach

- Probabilistic approach to verification worked very well
 - Analytic problem indicated errors in implementation of new feature that would not have been detected easily!
 - Verification of MCNP's PHT-VR work required violating the rules of code verifcation but not the spirit.
- Simplicity of test problem and data does not lower level of verification achieved
 - Data is so controllable, test problems can exercise parts of code that may not be stressed with ordinary test problems (eg (n,2n))
 - Design your own isotopes for your application!
- Can be applied to any transport code, independent of solution technique



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons





Summary: Probabilistic Approach

- Approach can be used to explore other problems
 - · Sensitivity studies
 - · cross-sections (density, temperature) and boundaries
 - · Charged particle transport
 - Production of libraries for multi-group calculations



Motivation

Introduction Analytic Verification Probabilistic approach Pulse-height Spectra Verification Test Problem Verification Problem Solutio Pulse Height Results Photons Photons and Electrons





