

LA-UR-16-27166

Approved for public release; distribution is unlimited.

Title: DRIFT – A Detector Response Function Toolkit for MCNP® Output

Author(s): Andrews, Madison Theresa
Bates, Cameron Russell
Mckigney, Edward Allen
Sood, Avneet
Solomon, Clell Jeffrey Jr.

Intended for: Advances in Nuclear Nonproliferation Technology and Policy Conference,
2016-09-25/2016-09-29 (Santa Fe, New Mexico, United States)

Issued: 2016-09-20

Disclaimer:

Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the Los Alamos National Security, LLC for the National Nuclear Security Administration of the U.S. Department of Energy under contract DE-AC52-06NA25396. By approving this article, the publisher recognizes that the U.S. Government retains nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

DRIFT – A Detector Response Function Toolkit for MCNP® Output

M.T. Andrews, C.R. Bates, E.A. McKigney, A. Sood, C.J. Solomon
Monte Carlo Codes, Methods, & Applications, XCP-3

Demonstrating MCNP Correlated Fission & Associated Packages Workshop
Los Alamos National Laboratory



September 28th, 2016



Outline

- **Why use DRiFT?**
- **What is DRiFT**
- **Modelling an EJ301 measurement**
 - Measurement description
 - Measurement results
 - Simulation description
 - DRiFT Modeling process
 - DRiFT results
- **DRiFT availability**

Why use a detector response package

Why model detectors:

- Accurate detector modeling is a requirement to design systems in many radiation detection scenarios.
 - By determining a Detector's Response Function (DRF) to incident radiation, we can characterize unknown sources.
- More efficient design processes (cost and time)
- Realistic radiation sources may not be available

Why not use just MCNP:

- MCNP has transport physics but no standard framework for detector effects (ad-hoc methods have been added)
- Modern experiments require modeling the entire detector system
 - EJ301 Scintillator: proton recoil (MCNP), **scintillation light production**, scintillation light transport, **PMT gain**, **digitization (ADC or MCA)**

DRiFT – A Detector Response Function Toolkit

- Under-development at Los Alamos National Laboratory
- Intended to post-process MCNP® output and create realistic detector spectra.
 - Leverages the ability of MCNP® to simulate complex radiation sources, materials and geometries.
 - DRiFT includes detector physics not present in many radiation transport codes.
- Capabilities currently under development include the simulation of semiconductor, gas, and as will be discussed in this work, scintillator detector physics.

DRiFT design


- Modern C++ 11 based framework
- Main routine:
 - Read configuration file
 - Read primary datafile into memory (PTRAC or mctal)
 - Perform detector modelling steps as specified in configuration
- Each process (digitization, PMT effects, scintillation) can be a standalone C++ class which accepts some set of data objects (energy histogram, list mode recoil events, etc.) and returns a process data object decided by the application developer
- Different combinations of processing can be performed on the same set of original data for trade-off studies

DRiFT Organic Scintillator Simulation Capabilities


- Focus of the remainder of this presentation.
- Work began mid-2015, most mature DRiFT capability
- DRiFT simulations have been compared to neutron and photon measurements of complex energy spectra, and pulse shape trends as measured by EJ-301 detectors.

Scintillation Measurements

- Sources were placed 70 cm from the front of an cylindrical scintillator coupled to a PMT.
- ^{252}Cf and PuBe neutron sources
- ^{228}Th and ^{22}Na sources used for gamma measurements.
- Detector – EJ 301 Liquid Scintillation
- Pulses are recorded and post-processed in the data analysis framework ROOT.




Scintillation Measurements



- Light produced is quoted in MeVee
- Conversion of proton energy into MeVee is non-linear.
- Light output intensity is time-dependent and unique to incident radiation (photon vs. neutron).

- Measured EJ-301 scintillation pulses from incident neutron and photons.


Scintillation Measurements



$$PSD = \frac{Q_s - Q_f}{Q_s}$$

- Tail to total PSD value as a function of energy

Scintillation Measurements



$$PSD = \frac{Q_s - Q_f}{Q_s}$$

- Extracted neutron and photon spectra after pulse shape discrimination

MCNP6® Simulations of organic scintillators

Scintillator is given a density and atomic ratio corresponding to manufacturer specs:

Detector	Type	H:C Ratio	Density / g cm ⁻³	Scintillation Yield
EJ-301	Liquid	1.212	0.874	12,000 γ/MeVee
EJ-212	Plastic	1.103	1.020	10,000 γ/MeVee

- MCNP Intrinsic Source Calculator (MISC) is used to create source photon spectra.
- Particle TRACKing (PTRAC) card used to record recoil proton's energy, and time as a binary.
 - PTRAC files are post-processed with mcnpTools

DRIFT Simulations

- DRIFT reads an input file containing keywords
- DRIFT reads the PTRAC file by calling mcnpTools
- Currently protons, electrons, alphas, deuterons, helium-3, tritons are supported.

[global]		
Datasource	=	mcnp
Datafile	=	ocf252p
Modeltype	=	event (ptrac)
[Scintillation]		
Detector	=	EJ301
Particle0	=	Proton
Particle1	=	electron
Quenching_data	=	Dekempeener
S_gate	=	22e-9
L_gate	=	90e-9
Sampling_rate	=	500e6
PMTType	=	9821B

DRiFT Simulations – Calculating Photo-electrons

- DRiFT treats each particle separately to properly determine the amplitude and shape of the resulting pulse.
- The PTRAC particle's electron equivalent energy (MeVee) is determined for the specific particle type and original energy using quenching data specified in input.
- The scintillation yield (12,000 photons/MeVee for EJ-301) is used to determine the mean number of photons produced.
- The actual number is sampled from a Poisson distribution.


DRIFT Simulations – Simulating Pulse Shape

- Optical photons are distributed in time using pre-defined intensity profiles.
- For histories with more than one recoil, the relative difference in time stamps is used to determine the initiation of their contribution to the overall count.
- Time interval sizes are matched to the sampling rate of the digitizer
- Optical transport factor and quantum efficiency factors are applied to photons. The remaining number of photons/electrons is sampled from a Poisson distribution.
- Shot noise and gain contributions are included in the calculation of the PMT current.

DRIFT Simulations – Additional Features


- Can convert PMT current into ADC units
- Set: Threshold, bits, range
- Study common digitizer effects:
 - ADC threshold effects with noise in waveform
 - Clipped pulses
 - Loss of spectral resolution due to ADC resolution
- Flexibility when calculating Pulse Shape Discrimination (PSD) values.
 - User can specify the long and short time gates used

Results – Photon Spectra Comparisons




Real energy broadening is slightly larger than predicted from theory

Results – Neutron Spectra Comparisons




- DRiFT can be used to compare different light output models

Results – Neutron Spectra Comparisons





- Best model compares well with finer binning

Results – Neutron Spectra Comparisons




Same model
works well for
²⁵²Cf

Results – Pulse Shape Discrimination Plots: Cf-252




DRiFT accurately reproduces n/ γ pulse shapes as a function of energy

Additional Features: Detector Selection



Additional Features: Trigger Thresholds



Trigger threshold effects can be accurately simulated if waveform noise is well modeled

DRiFT Availability

- Available for friendly testing on LANL HPC computers.
 - Point of Contact: Cameron Bates batesca@lanl.gov
- Planned public release with MCNP 6 in late 2016

Conclusions & Future Work


- The capabilities of DRiFT to simulate organic scintillation response have been demonstrated.
- DRiFT is flexible, allowing the user to specify PMT type, quenching data scintillation material, and trigger thresholds.
- Energy spectra and pulse shape discrimination (PSD) trends for incident photon and neutron radiation have been reproduced by DRiFT.
- We are working with those designing correlated prompt fission data measurements at LANL.
- Future work includes an expansion of scintillator simulation capabilities, semiconductor, and gas detector response functions.

Thank you. Questions?


- **Acknowledgements:**
 - Funding for this work was provided by the Los Alamos National Laboratory Directed Research and Development (LDRD) program.
 - Measurement data from K. Meierbachtol is greatly appreciated.

Supplemental Slides

Results – Pulse Shape Discrimination Plots: Na-22




(a) Measured




(b) DRiFT


Results – Photon Spectra Comparisons




Additional Features: Clipping Pulses



Future Work: Gas Detector Simulations




(a) Gmsh generated 3D Mesh




(b) Potential as a function of distance from anode

- An example of the detailed mesh generated by Gmsh (left) and the resulting electric potential (right) which is used by Garfield++ to calculate relevant detector properties.


Additional Features: Trigger Thresholds



Results – Neutron Spectra Comparisons



(a) MCNP 0.2 - 1.75 MeVee



(a) DRiFT 0.2 - 1.75 MeVee